



NOTES:

1. ATTACH WOOD NAILER TO WALL/DECK IN ACCORDANCE WITH FMRC GUIDELINES, AS PER SECTION 1-28, REGARDING WINDLOADS TO ROOF SYSTEMS AND DECK SECUREMENT.
2. WOOD BLOCKING MAY BE SLOTTED FOR VENTING OF WET-FILL DECKS OR OTHER APPLICABLE CONSTRUCTIONS.
3. POLYGLASS RECOMMENDS ALL ROOF EDGE TERMINATIONS BE DESIGNED AND INSTALLED IN ACCORDANCE WITH ANSI/SPRI ES-1.

**RAISED PERIMETER
EDGE WITH METAL
FLASHING**

NUMBER:
PG-EDGE-006

DATE:
July 2011



Polyglass USA, Inc.
1111 W. Newport Center Dr.
Deerfield Beach, FL 33442
www.polyglass.com