

## TECHNICAL BULLETIN

POLYGLASS USA Inc.  
Corporate Office  
1111 West Newport Center Drive  
Deerfield Beach, Florida 33442  
Tel. (954) 233-1330 - Fax: (954) 418-4453  
Email: [technical@polyglass.com](mailto:technical@polyglass.com)  
Website: [www.polyglass.com](http://www.polyglass.com)

### Technical Bulletin #2003-03 (Revised 2011)

TO: All POLYGLASS Users

CC: POLYGLASS Sales & Technical Services

Date: February 05, 2011

Author: Steven C. Wadding RRC,RRO,CDT  
Technical Services Manager

RE: Installation Techniques Self-Adhesive (SA) Membranes

Effective the date of the original Technical Bulletin, the installation technique herein below will be required and applicable to all Polyglass self-adhesive membrane manufactured for steep-slope and low sloped roofing designs.

Polyglass requires as part of the installation of all SA membranes, the installed membrane be rolled with a weighted roller with a minimum of 50 lbs for steep-slope and 80 lbs for low-sloped conditions. Brooming of SA membrane is no longer recommended to ensure sufficient contact between membrane and substrate surfaces.

Blind back-nailing of self-adhesive membranes systems at lap locations is recommended on all slopes greater than 1 inch per foot.

Polyglass recommends that safe work practices be used when using a weighted roller, especially on steep-slope roof conditions. Polyglass assumes no liability for damage or injury during the execution of its products. Installers can consult published safety standards by OSHA, NRCA, state and local building codes.

Special circumstances and questions should be addressed to POLYGLASS Technical Services Department.

02/05/2011  
SCW